

IMPORTANT

This template must be printed to full scale on 11" x 17" paper to accurately measure a door jamb for a Barracuda device. Simply print, cut out the black area, and place it against your door jamb as instructed on the template.

Slide this edge against jamb on outside of room

THE BARRACUDA™

**DSI Model Selector
for Inward Swinging Doors**

Use this side to measure left side of door jamb
(See reverse to measure right side)

Slide this edge against jamb in doorway opening

Barracuda Model Numbers

- DSI-2
- DSI-1
- DSI-3
- DSI-4
- DSI-5
- DSI-6

The arrow that lines up with the width of the door jamb indicates the model number needed.

www.bilco-barracuda.com